

**GigaDevice Semiconductor Inc.**

**GD32F330K-START**  
**Arm<sup>®</sup> Cortex<sup>®</sup>-M4 32-bit MCU**

**User Guide**

Revision 1.0

(Mar. 2022)

# Table of Contents

<b>TABLE OF CONTENTS</b> .....	<b>1</b>
<b>LIST OF FIGURES</b> .....	<b>2</b>
<b>LIST OF TABLES</b> .....	<b>3</b>
<b>1. SUMMARY</b> .....	<b>4</b>
<b>2. FUNCTION PIN ASSIGNMENT</b> .....	<b>4</b>
<b>3. GETTING STARTED</b> .....	<b>4</b>
<b>4. HARDWARE LAYOUT OVERVIEW</b> .....	<b>5</b>
<b>4.1. Power supply</b> .....	<b>5</b>
<b>4.2. Boot option</b> .....	<b>5</b>
<b>4.3. LED</b> .....	<b>5</b>
<b>4.4. KEY</b> .....	<b>5</b>
<b>4.5. GD-Link</b> .....	<b>6</b>
<b>4.6. MCU</b> .....	<b>6</b>
<b>5. ROUTINE USE GUIDE</b> .....	<b>7</b>
<b>5.1. GPIO_Running_LED</b> .....	<b>7</b>
5.1.1. DEMO purpose .....	7
5.1.2. DEMO running result .....	7
<b>5.2. GPIO_Key_Polling_mode</b> .....	<b>7</b>
5.2.1. DEMO purpose .....	7
5.2.2. DEMO running result .....	7
<b>5.3. EXTI_Key_Interrupt_mode</b> .....	<b>8</b>
5.3.1. DEMO purpose .....	8
5.3.2. DEMO running result .....	8
<b>5.4. TIMER_Key_EXTI</b> .....	<b>8</b>
5.4.1. DEMO purpose .....	8
5.4.2. DEMO running result .....	8
<b>6. REVISION HISTORY</b> .....	<b>10</b>

# List of Figures

Figure 4-1. Schematic diagram of power supply.....	5
Figure 4-2. Schematic diagram of boot option .....	5
Figure 4-3. Schematic diagram of LED function .....	5
Figure 4-4. Schematic diagram of Key function .....	5
Figure 4-5. Schematic diagram of GD-Link.....	6
Figure 4-6. Schematic diagram of MCU.....	6

# List of Tables

Table 2-1. Function pin assignment .....	4
Table 6-1. Revision history .....	10

## 1. Summary

GD32F330K-START uses GD32F330K8T6 as the main controller. It uses Mini USB interface to supply 5V power. Reset, Boot, Wakeup key, LED, GD-Link are also included. For more details please refer to GD32F330K-START-V1.0 schematic.

## 2. Function pin assignment

Table 2-1. Function pin assignment

Function	Pin	Description
LED	PA8	LED1
RESET	-	K1-Reset
KEY	PA0	K2-Wakeup

## 3. Getting started

The EVAL board uses Mini USB connector to get power DC +5V, which is the hardware system normal work voltage. A GD-Link on board is necessary in order to download and debug programs. Select the correct boot mode and then power on, the LEDPWR will turn on, which indicates that the power supply is OK.


There are Keil version and IAR version of all projects. Keil version of the projects are created based on Keil MDK-ARM 4.74 uVision4. IAR version of the projects are created based on IAR Embedded Workbench for ARM 7.40.2. During use, the following points should be noted:

1. If you use Keil uVision4 to open the project. In order to solve the "Device Missing (s)" problem, you can install GigaDevice.GD32F3x0\_DFP.3.0.0.pack.
2. If you use IAR to open the project, install IAR\_GD32F3x0\_ADDON\_3.0.0.exe to load the associated files.

## 4. Hardware layout overview


### 4.1. Power supply

Figure 4-1. Schematic diagram of power supply




### 4.2. Boot option

Figure 4-2. Schematic diagram of boot option




### 4.3. LED

Figure 4-3. Schematic diagram of LED function




### 4.4. KEY

Figure 4-4. Schematic diagram of Key function




## 4.5. GD-Link

Figure 4-5. Schematic diagram of GD-Link



## 4.6. MCU

Figure 4-6. Schematic diagram of MCU



## 5. Routine use guide

### 5.1. GPIO\_Running\_LED

#### 5.1.1. DEMO purpose

This demo includes the following functions of GD32 MCU:

- Learn to use GPIO control the LED
- Learn to use SysTick to generate 1ms delay

GD32F330K-START board has one LED. The LED1 is controlled by GPIO. This demo will show how to light the LED.

#### 5.1.2. DEMO running result

Download the program <01\_GPIO\_Running\_LED> to the EVAL board, LED1 will turn on and off in sequence with interval of 1s, repeat the process.

### 5.2. GPIO\_Key\_Polling\_mode

#### 5.2.1. DEMO purpose

This demo includes the following functions of GD32 MCU:

- Learn to use GPIO control the LED and the Key
- Learn to use SysTick to generate 1ms delay

GD32F330K-START board has two keys and one LED. The two keys are Reset key and Wakeup key. The LED1 is controlled by GPIO.

This demo will show how to use the User key to control the LED1. When press down the Wakeup Key, it will check the input value of the IO port. If the value is 1 and will wait for 50ms. Check the input value of the IO port again. If the value is still 1, it indicates that the button is pressed successfully and toggle LED1.

#### 5.2.2. DEMO running result

Download the program <02\_GPIO\_Key\_Polling\_mode> to the EVAL board, LED1 will flash once for test and then turn on, press down the Wakeup Key, LED1 will be turned off. Press down the Wakeup Key again, LED1 will be turned on.



## 5.3. EXTI\_Key\_Interrupt\_mode

### 5.3.1. DEMO purpose

This demo includes the following functions of GD32 MCU:

- Learn to use GPIO control the LED and the KEY
- Learn to use EXTI to generate external interrupt

GD32F330K-START board has two keys and one LED. The two keys are Reset key and Wakeup key. The LED1 is controlled by GPIO.

This demo will show how to use the EXTI interrupt line to control the LED1. When press down the Wakeup Key, it will generate an interrupt. In the interrupt service function, the demo will toggle LED1.

### 5.3.2. DEMO running result

Download the program <03\_EXTI\_Key\_Interrupt\_mode> to the EVAL board, LED1 will flash once for test and then turn on, press down the Wakeup Key, LED1 will be turned off. Press down the Wakeup Key again, LED1 will be turned on.

## 5.4. TIMER\_Key\_EXTI

### 5.4.1. DEMO purpose

This demo includes the following functions of GD32 MCU:

- Learn to use GPIO control the LED and the KEY
- Learn to use EXTI to generate external interrupt
- Learn to use TIMER to generate PWM

GD32F330K-START board has two keys and one LED. The two keys are Reset key and Wakeup key. The LED1 is controlled by GPIO.

This demo will show how to use the Wakeup Key and TIMER PWM to trigger EXTI interrupt line to toggle the state of LED1. When press down the Wakeup Key, it will produce an interrupt. In the corresponding interrupt service function, the demo will toggle LED1. When connect PA6(TIMER2\_CH0) and PA4 with DuPont line, EXTI interrupt occurs on the falling edge of the PWM signal. In the corresponding interrupt service function, the demo will toggle LED1.

### 5.4.2. DEMO running result

Download the program <04\_TIMER\_Key\_EXTI> to the EVAL board, LED1 will flash once

for test, press down the Wakeup Key, LED1 will be turned on. Press down the Wakeup Key again, LED1 will be turned off. Connect PA6(TIMER2\_CH0) and PA4 with DuPont line. The LED1 will be toggled every 500ms.

## 6. Revision history

Table 6-1. Revision history

Revision No.	Description	Date
1.0	Initial Release	Mar.06, 2022

## Important Notice

This document is the property of GigaDevice Semiconductor Inc. and its subsidiaries (the "Company"). This document, including any product of the Company described in this document (the "Product"), is owned by the Company under the intellectual property laws and treaties of the People's Republic of China and other jurisdictions worldwide. The Company reserves all rights under such laws and treaties and does not grant any license under its patents, copyrights, trademarks, or other intellectual property rights. The names and brands of third party referred thereto (if any) are the property of their respective owner and referred to for identification purposes only.

The Company makes no warranty of any kind, express or implied, with regard to this document or any Product, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. The Company does not assume any liability arising out of the application or use of any Product described in this document. Any information provided in this document is provided only for reference purposes. It is the responsibility of the user of this document to properly design, program, and test the functionality and safety of any application made of this information and any resulting product. Except for customized products which has been expressly identified in the applicable agreement, the Products are designed, developed, and/or manufactured for ordinary business, industrial, personal, and/or household applications only. The Products are not designed, intended, or authorized for use as components in systems designed or intended for the operation of weapons, weapons systems, nuclear installations, atomic energy control instruments, combustion control instruments, airplane or spaceship instruments, transportation instruments, traffic signal instruments, life-support devices or systems, other medical devices or systems (including resuscitation equipment and surgical implants), pollution control or hazardous substances management, or other uses where the failure of the device or Product could cause personal injury, death, property or environmental damage ("Unintended Uses"). Customers shall take any and all actions to ensure using and selling the Products in accordance with the applicable laws and regulations. The Company is not liable, in whole or in part, and customers shall and hereby do release the Company as well as its suppliers and/or distributors from any claim, damage, or other liability arising from or related to all Unintended Uses of the Products. Customers shall indemnify and hold the Company as well as its suppliers and/or distributors harmless from and against all claims, costs, damages, and other liabilities, including claims for personal injury or death, arising from or related to any Unintended Uses of the Products.

Information in this document is provided solely in connection with the Products. The Company reserves the right to make changes, corrections, modifications or improvements to this document and Products and services described herein at any time, without notice.